

G Code Table

The following table lists the G codes, identifies the defaults (in the shaded areas), lists Modal (M) or Non-modal (N) types, identifies groups, and describes the G codes' functions.

Some G codes are strictly BNC or strictly ISNC, and are identified as such in this manual. Otherwise, the G codes apply to either dialect.

G Code	Type	Group	Function
G00	M	01	Positioning (Rapid Traverse)
G01	M		Linear Interpolation (Cutting Feed)
G02	M		Circular Interpolation/Helical CW
G02.4	M		3D Circular Interpolation CW
G03	M		Circular Interpolation/Helical CCW
G03.4	M		3D Circular Interpolation CCW
G04	N	00	Dwell, Exact Stop
G05.1	M	19	Surface Finish Parameters
G05.2	M	19	Data Smoothing
G09	N	00	Decelerate Axis to Zero
G10	N		Data Setting
G11	N		Data Setting Mode Cancel
G15	M	17	Polar Coordinates Cancel
G16	M		Polar Coordinates
G17	M	02	XY Plane Selection
G18	M		ZX Plane Selection
G19	M		YZ Plane Selection
ISNC G20	M	06	Input in Inch
ISNC G21	M		Input in mm
G28	N	00	Return to Reference Point
G29	N		Return from Reference Point
G31	N		Skip Function

Continued

G Code	Type	Group	Function (Continued)
G40	M	07	Cutter Compensation Cancel
G41	M		Cutter Compensation Left
G42	M		Cutter Compensation Right
G43	M	08	Tool Length Compensation + Direction
G44	M		Tool Length Compensation - Direction
G45	N	00	Tool Offset Increase
G46	N		Tool Offset Decrease
G47	N		Tool Offset Double Increase
G48	N		Tool Offset Double Decrease
G49	M	08	Tool Length Offset Compensation Cancel
G50	M	11	Scaling Cancel
G51	M		Scaling
G50.1	M	18	Mirroring Cancel
G51.1	M		Mirroring
G52	N	00	Local Coordinate System Setting
G53	N		Machine Coordinate System Selection
G54	M	14	Work Coordinate System 1 Selection
G55	M		Work Coordinate System 2 Selection
G56	M		Work Coordinate System 3 Selection
G57	M		Work Coordinate System 4 Selection
G58	M		Work Coordinate System 5 Selection
G59	M		Work Coordinate System 6 Selection
G61	M	15	Decelerates to Zero–Precision Cornering
G64	M		Cancels Precision Cornering
G65	N	12	Macro Command, Subprogram Call
G66	M		Modal Subprogram Call
G67	M		Modal Subprogram Call Cancel
G68	M	16	Coordinate Rotation
G69	M		Coordinate Rotation Cancel
BNC G70	M	06	Input in Inch
BNC G71	M		Input in mm
G73	M	09	Peck Drilling Cycle
ISNC G74	M		Left-handed Tapping Cycle
ISNC G74 with M29	M		Rigid Tapping

G Code	Type	Group	Function (Continued)
BNC G74	M	01	Single-quadrant Circular Interpolation
BNC G75	M		Multi-quadrant Circular Interpolation
G76	M	09	Bore Orient Cycle
G80	M		Canned Cycle Cancel
G81	M		Drilling Cycle, Spot Boring
G82	M		Drilling Cycle, Counter Boring
G83	M		Peck Drilling Cycle
G84	M		Tapping Cycle
ISNC G84.2	M		Rigid Tapping Cycle
ISNC G84.3	M		Rigid Tapping Cycle
ISNC G84 with M29	M		Rigid Tapping Cycle
G85	M		Boring Cycle
BNC G86	M		Bore Orient Cycle
ISNC G86	M		Bore Rapid Out Cycle
BNC G87	M		Chip Breaker Cycle
ISNC G87	M		Back Boring Cycle
BNC G88	M		Rigid Tapping Cycle
ISNC G88	M		Boring Cycle Manual Feed Out, Dwell
G89	M		Boring Cycle Bore and Dwell
G90	M	03	Absolute Command
G91	M		Incremental Command
G92	N	00	Programming of Absolute Zero Point
G93	M	05	Inverse Time
G94	M		Feed per Minute
G98	M	10	Return to Initial Point in Canned Cycle
G99	M		Return to R Point in Canned Cycle

Table 3. G Codes in order of Codes